

Rolfstone Nova

Truly wireless sport earbuds



EN User Manual

Earbuds overview



Charging case overview



Front view



Rear view



Connect for the first time

A manual connection must be made when the earbuds have not been connected to a Bluetooth device before.

1. Get both earbuds out of the charging case.
2. Both earbuds will automatically turn on (ascending tone) and connect to each other.
3. Place both earbuds in your ears.
4. The earbuds will now search for a Bluetooth device.
5. Open the Bluetooth settings on your device and activate Bluetooth.
6. Wait until Rolfstone Nova appears and select it. The earbuds are ready for use.

! *More information and instruction videos can be found on www.rolfstone.com/support*

Automatically reconnect

When the earbuds have been connected to a device before then the earbuds only need to be turned on to automatically reconnect with the device.

1. On the previously connected device:
 - Bluetooth must be enabled.
 - Rolfstone Nova needs to be in the list of devices.
2. Get both earbuds out of the charging case.
3. Both earbuds will automatically turn on (ascending tone) and connect to each other.
4. Place both earbuds in your ears.
5. Hereafter the Rolfstone Nova will search for a known Bluetooth device and automatically connect to it.

! *More information and instruction videos can be found on www.rolfstone.com/support*

Disconnect the earbuds

Open the Bluetooth settings on your device and disconnect the Rolfstone Nova.

The earbuds are now free to connect to another device.

If you want to reconnect the earbuds later, follow the steps on page 4.

Good to know

- The earbuds and the device must be within 10 meters (or 33 feet) of each other. Intermediate objects such as walls can shorten the range.
- The earbuds can only be connected to one device at a time.
- The Rolfstone Nova earbuds will automatically turn off when placed in the charging case.
- More information and instruction videos can be found at www.rolfstone.com/support
- If you still have questions, please do not hesitate to contact us (page 12).

Charging the Rolfstone Nova

When the Rolfstone Nova earbuds are fully charged they will last 5 hours.

When the earbuds are almost empty you will hear a short descending tone. Shortly after that the earbuds will be disconnected.

- Place the earbuds into the charging case. Make sure that the charging contact points (page 2) are properly connected to the contact points in the charging case.
 - When the earbuds are placed in the charging case two red lights will light up on the front of the charging case.
 - If both lights are not turned on the charging case is empty.
- To fully charge the earbuds will take about 40 minutes. When the earbuds are fully charged the lights on the front of the charging case will turn off. Each earbud may have a different charging time.
- Make a habit of storing the earbuds in the charging case after use. This way they stay together, are well protected and are fully charged for future use.

Charging the charging case

A fully charged charging case allows you to charge the earbuds 4 times on the go.

If the charging case itself is almost empty a red light will flash on the back of the case.

- Connect the charging case to a charger or laptop/desktop computer using the micro USB cable.
- The charging case takes about 50 minutes to fully charge. During charging, the red light on the back flashes.
- The charging case is full when the red light on the back is lit continuously.

! The battery life of the earbuds may be shorter at higher music volumes and lower temperature conditions.

Rolfstone Nova in use

The Rolfstone earbuds are very suitable for sports because the earbuds are small and stay perfectly in place during any activity.

To stay in place it is important that the earbuds are correctly placed in the ears.

- Gently push the eartips into the ear canal.
- At the top of the earbuds is a wingtip (page 2). Make sure that the wingtip clamps with the auricle.

For an optimal fit, several types of eartips are included.

The eartip can easily be changed.

- ! **The Rolfstone Nova earbuds are rain and sweat resistant. However, they are not completely waterproof. Do not wash them under running water or use them underwater.**

Functions & control

The control button (page 2) allows you to select music and make calls without touching your mobile phone.

Play / Pause

Press 1x

Next track

Press 2x

Previous track

Press 3x

Accept incoming call / end a call

Press 1x

Reject incoming call

Press 2 sec.

Turn Rolfstone Nova on and off

Press 3 sec.

Important

Do not expose your ears to high noise levels for long periods of time to avoid hearing damage.

Be aware that when using earbuds the ambient noise is less noticeable. This can cause dangerous situations. So pay extra attention and don't put yourself and your environment in danger.

Warranty

The Rolfstone Nova earbuds and charging case come with a one year warranty. If you encounter problems within this period that are not the result of improper use or damage due to external influences, please contact us (page 12).

Service & contact

More information and instruction videos can be found at www.rolfstone.com/support.

Do you have questions? Then feel free to contact us. We think it's important that everyone can enjoy the Rolfstone Nova to the fullest.

- Email: info@rolfstone.com
- Whatsapp: +31 6 83 99 39 93
- Phone: +31 6 83 99 39 93

Contact us during office hours (Central European Time). Does this not suit you? Send us a WhatsApp message or email and we will respond the next working day.

Have fun using the Rolfstone Nova truly wireless earbuds!